
Bitron AV1407/001 (4+n) T-Line







Terminals

AU, AU	Aux Button
1	Speech In (Speaker)

2 Speech Out (Mic)

9 Lock

6 Common

P Local Call (switched)

C7 Call From Panel

IMPORTANT NOTE:


- 1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, <u>do not</u> short them out).
- 2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.
- 3) Some systems may have <u>loop on wiring</u>, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

Bitron AV1407/001

AV 1407/002 AV 1407/004

1 + n


Riser



AV 1407/001 AV 1407/003


4 + n

Riser



Wiring Diagram

Bitron Domular 3000 5 Wire Audio



Wiring Diagram

Bitron Domular 3000 2 Entrance System

