


Fermax 2044



Terminals

- 1 Lock
- 2 Speech Out (Mic)
- 3 Common
- 6 Speech In (Speaker)
- 4 Call

IMPORTANT NOTE :

1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).


2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

Wiring Diagram


1 Way Basic Audio

INSTALLATION



Wiring Diagram

5 Wire Audio System



SECTION TABLE


Distances up to 300 meters

—————	1 mm ²
—————	0.5 mm ²

Calls
To the call terminal (4) of each telephone.

Wiring Diagram

5 Wire Audio with 2 Entrances



SECTION TABLE

Distances up to 300 meters

—————	1 mm ²
- - - - -	0.5 mm ²