

# Fermax NR-0104



## Terminals

- 1 Lock
- 2 Speech Out (Mic)
- 3 Common
- 6 Speech In (Speaker)
- 4ll Call
- 5op Not Used

**Replacement is now Fermax 8044**


## IMPORTANT NOTE :

- 1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).
- 2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.
- 3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

# Wiring Diagram


## 1 Way Basic Audio

### INSTALLATION



# Wiring Diagram

## 5 Wire Audio System



# Wiring Diagram

## 5 Wire Audio with 2 Entrances

