STATUS (SML) 1130/NID

Terminals

1	Additionl PCB	
CA	F, P,G	L,O,6
2		
6		
10		
9		

IMPORTANT NOTE :

1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have loop on wiring, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

© 2013 www.interfoni.rs

WIRING DETAILS



NOTE : There are many different versions of the handsets for STATUS (SML), so a picture of the insides and terminal markings is the best way to get a positive identification.

SML-1130/1	Standard Handset (Mechanical Buzzer) + 1 Button
SML-1130/N	Urmet Modified Handset to N
SML-1130/NI	Urmet Modified Handset to NI
SML-1130/NID	Urmet Modified Handset to NID (Mechanical Buzzer)
SML-1130/NIDP	Urmet Modified Handset to NIDP
SML-1130/T	Urmet Modified Handset to T (Mechanical Buzzer)
SML-1130/TSL	Urmet Modified Handset to TSL (Mechanical Buzzer)
SML-1131/1	Standard Handset (Electronic Tone) + 1 Key
SML-1131/N	Urmet Modified Handset to N
SML-1131/NI	Urmet Modified Handset to NI (Electronic Tone)
SML-1131/NID	Urmet Modified Handset to NID (Electronic Tone)
SML-1131/NIDP	Urmet Modified Handset to NIDP (Electronic Tone)
SML-1131/CNID	Urmet Modified Handset to CNID
SML-1131/T	Urmet Modified Handset to T (Electronic Tone)
SML-1131/DC	Urmet Modified Handset to DC (Electronic Tone)
SML-1131/DCP	Urmet Modified Handset to DCP (Electronic Tone)
AT-PID	Telephone c/w Privacy Button, Indicator & Door Open
AT-PID/C	Telephone c/w Privacy Button, Indicator, Door Open & Concier

© 2013 www.interfoni.rs